PARIS







A few tips from EGO Paris

to look after your furniture properly

Saline environments are corrosive and even very high quality materials suffer from these conditions if they are not properly maintained. Thus we recommend you to rinse your furniture regularly in order to remove salt deposits. We also advise you to cover them and to store them inside when you are not using them.

We propose protective covers for your EGO Paris furniture.

We draw your attention to the risks incurred by application of chemicals, the active principles whose have not been validated by the manufacturer.

We recommend that you do not leave dirt or objects on your furniture for more than 24 hours in order to avoid to stain their surfaces.

	Lacquered aluminium	Teak	Ash	Corian®	Glass	Ceramic Dekton®
Technical specifications	Thermo-coated aluminium with polyester powder of architectural quality (Alesta by Axalta). Excellent UV and weather resistance. Standard profiles are 2mm thick.	Naturally rot-proof, treated wood.	Natural wood coming from French forests. High temperature treatment gives wood remarkable properties: better resistance to fungal attacks / better dimensional stability / increased durability.	Solid, non-porous and homogeneous surfacing materials made of acrylic resin and natural minerals. In normal conditions of use, Corian® is wear, shock and scratch resistant.	The table tops are made of 6mm Sécurit tempered glass.	100% mineral ultracompact surface made by blend raw materials used to produce glass and porcelain. Non porous material. UV, frost, shock and scratch resistant.
Maintenance conditions/ regular cleaning	Regularly cleanse the lacquered aluminium parts, at least every 6 months, and more frequently in saline and commercial environments. Wash with soapy water, rinse, then wipe with a soft cloth.	Nourish furniture regularly with specific oils to slow down the darkening process.	Without maintenance, your ash will turn into a beautiful silver gray colour. To preserve its original colour, we advise you to treat it once or twice a year.	Cleanse with soapy water, rinse, then wipe with a soft cloth.	Cleanse with soapy water, rinse, then wipe with a soft cloth. Clean the silicone seals with bathroom cleaning products.	Cleanse with soapy water, rinse, then wipe with a soft cloth.
Maintenance conditions/ stubborn stains	Use specialised cleaning products for lacquered surfaces (for outdoor furniture or cars). In event of scratches on paint, EGO Paris can provide you touch-up kits to prevent the spread of the corrosion.	EGO Paris recommends you to use Starbrite products www.starbrite.com	EGO Paris recommends you to use Starbrite products www.starbrite.com	Refer to the specific instructions on the website www.dupontdenemours.fr	Refer to the specific instructions on the website www.saintgobain-vitrage.fr	www.dekton.fr
Warranties	less than 1km from the sea. Paint peeling caused by scratches is not covered by the guarantee. The guarantee does not apply in event of	wood are guaranteed for 5 years (PRIVATE use) or for 2 years (COMMERCIAL use). The guarantee does not apply in event of force majeure, excessive wear or abnormal use. Wood is a living material, the aspect and colour evolve over time and can vary from	The mechanical properties of wood are guaranteed for 5 years (PRIVATE use) or for 2 years (COMMERCIAL use). The guarantee does not apply in event of force majeure, excessive wear or abnormal use. Wood is a living material, the aspect and colour evolve over time and can vary from one production to another.	The guarantee for 5 years (PRIVATE use) or for 2 years (COMMERCIAL use) does not apply in event of force majeure, excessive wear or abnormal use.	The glass tops are guaranteed for 5 years (PRIVATE use) or for 2 years (COMMERCIAL use), excepting lacquer scratches under the surface. The silicone seals are guaranteed anti- mould for 2 years. The guarantee does not apply in event of force majeure, excessive wear or abnormal use.	The guarantee for 5 years (PRIVATE use) or for 2 years (COMMERCIAL use) does not apply in event of force majeure, excessive wear or abnormal use.
Green	Recyclable and reusable. Paint is solvent and lead free.	Teak collected according to environmental policies.	Ash collected according to environmental policies.	Recyclable	Recyclable	

Extreme care must be paid when unpacking your furniture to prevent damaging it. Cutter strokes, staple scratches and scratches on table tops placed on the floor are not covered by the guarantee. No guarantees apply if the furniture has been disassembled.



EGO Paris furniture is designed and packaged in recyclable materials. To ensure our joint environmental protection responsibility, please take your end-of-life furniture and your packaging to your local dump site.

We do not recommend the use of protection covers that are not supplied by EGO Paris and we decline all responsibility in case of damages that might be caused by their use.







EGO Paris' maintenance guide for fabrics and meshes care

	Docril (F)	Sunbrella (T)	Stamskin Top / Top club(M)	Waterproof Fabric (W)	Elios (E)	Perennials (A)	Missoni Home (N)	Mesh (C)
Composition	100% solution-dyed acrylic fabric with a back coating	100% Solution-dyed acrylic	Synthetic leather (Serge Ferrari®)	Canvas of ultra-resistant polyester yarns coated with 100% solution dyed PVC and synthetic fibers. (Eden by Serge Ferrari®)	PVC (Ultra-resistant polyester yarns) and synthetic fibers solution- dyed. (Serge Ferrari®)	100% solution-dyed acrylic	100% Polyester	100% coated PVC threads/ batch-dyed
Technical characteristics	Highly resistant to UV and poor weather. Antifungal and water-repellent.		Waterproof, excellent UVA resistance, easy-care. Antifungal. Fire resistance M2.	Waterproof. Highly resistant to UV, moisture and mould.	Excellent abrasion resistance. Highly resistant to UV.	Excellent resistance to UV. Water-repellent and antifungal.	UV-resistant. Water- repellent. Anti-fungal.	Highly resistant to UV and distortion. Insusceptible to moisture and chlorine. Washable. Fast-drying. Recyclable.
Care instructions	For surface stains: clean with a soft brush and soapy water.Machine washable at 40°C.	For surface stains: clean with a soft brush and soapy water.Machine washable at 40°C. Cleaning recommendations according to stain type: https://www.sunbrella.c om/fr/ how-to-clean	Clean with a soft sponge and soapy water. Cleaning recommendations : https://www.youtube.com/watch?v=G BHd-0NWfNI&feature=youtu.be	Easy-care, clean with a soft sponge and soapy water.	Easy-care, clean with a soft sponge and soapy water.	Cleaning recommendations: https://www.perennialsfa brics.com/fabrics/about/ care/	N45-46-47: Hand-wash. Iron on the reverse side of the fabric.	Soapy water and gentle brushing if required, then rinse with clean water.